
KVH Industries, Inc.

A Guide to GyroTrac

- Installation Instructions
- User's Guide
- Technical Manual




GyroTrac™ Wiring Quick Reference Guide





Complete installation and wiring directions have been provided in Section 2, Installation.

GyroTrac™ Menu Quick Reference Guide



GyroTrac User's Manual Addendum



(ECO #5208, 5903, 7233)

The following changes have been made to Revision G of the GyroTrac User's Manual (KVH Part Number 54-0142).

2.5 Connecting to Vessel Power

The ADCU now has 3 fuses, two 1-amp resettable polyswitch fuses on the lower printed circuit board (PCB) and a 4-amp fuse on the upper PCB. Therefore, the sidebar tip should no longer refer to just one 1-amp fuse.

4 Troubleshooting

The three fuses in the ADCU differ in rating, as noted in the revised troubleshooting section.

Issue 2:

System is installed correctly and power is available, but the system is non-functional.

Solution:

Check the 4-amp fuse within the ADCU. Remove the two screws securing the top and the base of the ADCU. Remove the top of the ADCU. The 4-amp fuse is secured in brackets on the upper printed circuit board (PCB) within the unit. Remove the damaged fuse and replace with a new, functional fuse.

Two 1-amp fuses are mounted on the lower PCB. If these fuses trip, they will automatically reset once the offending device is removed from the circuit and the internal device temperature returns to normal.


Note: The fuses on the lower (main) PCB are 1-amp resettable polyswitch fuses. The fuse on the upper (interface) PCB is a 4-amp fast blow fuse.



The ADCU is equipped with **fuses** to protect against high-voltage spikes. If the system is installed correctly and power is available, but the system is non-functional, refer to Section 4, "Troubleshooting," for instructions on checking and replacing the **fuses**.

Figure 4-1

ADCU Fuse Locations
(Top Cutaway)



5.2 Replaceable Parts

The 1-amp fuse has been removed from the table of GyroTrac Field Replaceable Units. The new 1-amp resettable polyswitch fuses are mounted directly to the lower PCB and cannot be replaced in the field. However, the 4-amp fuse on the upper PCB, which can be replaced in the field, has been added to the table.

In addition, the part number for the sensor module has been changed to 02-1154. The table has been updated accordingly.

FRU	KVH Part No.
Sensor Module	02-1154
ADCU	02-0961
Flush Mount ADCU Panel	20-0667
Horizontal Sensor Bracket	20-0658
Vertical Sensor Bracket	20-0666
Connector Wire Terminal Strip	23-0223-12
Sensor to ADCU Data Cable	32-0623-30
ADCU Interface PCB Fuse, 4-amp	16-0017-4000

Table 5-1Field Replaceable Units

54-0142 Addendum to Rev. G

GyroTrac Owner's Manual Addendum

(ECO #5619)

The following changes have been made to Revision G of the GyroTrac Owner's Manual (KVH Part Number 54-0142).

Inside Front Cover

The quick reference guide on the inside front cover has been changed as follows:

- 1. The PIN Code Screens box has been deleted.
- 2. A menu item has been added to the column headed by "Control antenna?" (see Figure A below).




Figure A
New Menu Item on Quick
Reference Guide

3.2.3 System Security

This section of the manual has been deleted. The little-used security option is no longer available.

54-0142 Addendum to Rev. G


3.8 Control Antenna Mode

A new software feature has been added to the GyroTrac system – Satellite Frequency Scan. If the GyroTrac is connected to a TracVision G4 or TracVision G6, this option allows you to update the frequency data of any satellite stored in the system's library.

These screens are only seen if Antenna Comm is turned ON.


This sequence of steps allows a user to adjust the antenna's azimuth and elevation manually, restart the antenna, set Sleep Mode on or off, set Instant On Mode on or off, install a new pair of active satellites, set the latitude and longitude, select the active satellite system, and **update satellite frequency data**.

Figure 3-29Control Antenna Mode
Menu Sequence



3.8.7 Selecting Active Satellite

Figure 3-36 has been updated to include "Updating Satellite Frequency Data."



3.8.8 Updating Satellite Frequency Data

These screens are only seen if the GyroTrac ADCU is connected to a TracVision G4 or TracVision G6.

If you select a channel but it doesn't appear on the TV, the satellite's frequency data may have changed. The Satellite Frequency Scan feature allows you to update the frequency data of any satellite stored in the system's library.

With the desired satellite, band, and polarization selected, the system will automatically search for the frequency with the strongest signal. The system will then update that satellite's programmed data with the new frequency (and associated network ID) and store it in the satellite library.

To update the satellite frequency data, perform the following:

- 1. Place your IRD in the satellite signal meter mode.
- 2. Select the desired satellite on the ADCU. *Ensure the TV signal meter indicates that you have a strong signal.*



If the antenna is unable to find any channel on the selected satellite automatically, you can manually point the antenna using the Manual mode (see Section 3.8.1, "Manually Controlling the Antenna").

54-0142 Addendum to Rev. G

- 3. Select the desired polarization and band on the IRD.
- 4. *Do not move the vessel.* Your boat must remain motionless during the entire Satellite Frequency Scan process.
- 5. Follow the ADCU menus on the next page. The scan itself will take a couple of minutes. Once complete, restart the antenna and ensure the antenna will track the new frequency.

If you are unsure about when and how to use the Satellite Frequency Scan feature, please contact your dealer/installer or distributor for assistance.3




Figure 3-37
Satellite Frequency Scan



To find a valid symbol rate and FEC code, refer to an up-to-date satellite table either in a magazine or on the Internet. For your convenience, this data is available (for the system's predefined satellites) on our web site at www.kvh.com/footprint/index.html.

54-0142 Addendum to Rev. G



GyroTrac User's Manual Addendum

(ECO #5208)

The following changes have been made to Revision G of the GyroTrac User's Manual (KVH Part Number 54-0142).

2.5 Connecting to Vessel Power

The ADCU now has 2 fuses, a 1-amp fuse on the lower printed circuit board (PCB) and a 4-amp fuse on the upper PCB. Therefore, the sidebar tip should no longer refer to just one 1-amp fuse.

4 Troubleshooting

The two fuses in the ADCU differ in rating, as noted in the revised troubleshooting section.

Issue 2:

System is installed correctly and power is available, but the system is non-functional.

Solution:


Check the **fuses** within the ADCU. Remove the two screws securing the top and the base of the ADCU. Remove the top of the ADCU. The **fuses** are secured in brackets on the upper and lower printed circuit boards (PCBs) within the unit. Remove the damaged fuse and replace with a new, functional **fuse**.

Note: The fuse on the lower (main) PCB is a 1-amp fast blow fuse. The fuse on the upper (interface) PCB is a 4-amp fast blow fuse.



The ADCU is equipped with **fuses** to protect against high-voltage spikes. If the system is installed correctly and power is available, but the system is non-functional, refer to Section 4, "Troubleshooting," for instructions on checking and replacing the **fuses**.

Figure 4-1
ADCU Fuse Locations
(Top Cutaway)



5.2 Replaceable Parts

The Gyrotrac ADCU now contains two different fuses, necessitating the addition of the 4-amp fuse to the parts list.

Table 5-1 Field Replaceable Units

KVH Part No.
02-0991
02-0961
20-0667
20-0658
20-0666
23-0223-12
32-0623-30
16-0009-1000
16-0017-4000

GyroTrac Owner's Manual Addendum



(ECO #5206)

Due to a software revision designed to improve the GyroTrac's operation and user interface, some of the menu displays have been modified. The following pages of Revision G of the GyroTrac Owner's Manual (KVH Part Number 54-0142) have been updated to reflect these changes.


3.4.1 Setting the Sine/Cosine Data Output

The sine/cosine setup is done in three stages: first the magnetic or true heading option is selected, then the reference voltage is set, and finally the swing voltage is set. The valid range for reference and swing voltages is between 0 and 6.5 volts. **The default value for reference voltage is 2.5 volts. The default value for swing voltage is +/- 1.67 volts.** Refer to your autopilot manual for correct voltage requirements.


Figure 3-13
Setting Sine/Cosine Data Output




If the GyroTrac is receiving data from a ship's gyro, all compass outputs are automatically configured as True North and cannot be set as Magnetic. If this is the case, the following variation on the magnetic/true selection screen will be displayed:



If the system is NOT connected to a GPS or a ship's gyro, only magnetic heading data will be available and the following variation on the magnetic/true selection screen will be displayed:




The system will then proceed to the "Set Ref" screens.



3.4.2 Setting the Serial Outputs

The GyroTrac can output up to three serial messages simultaneously in any combination of NMEA version 2.2, KVH RS-422, or Cetrek proprietary format. NMEA message options and the KVH and Cetrek formats are described briefly in *Appendix C*. Follow the procedures illustrated below to set the serial outputs. The factory default speed setting is 10 Hz.






Custom configurations are not available on GyroTrac at this time.

3.4.2.1 Setting the NMEA Outputs

GyroTrac is fully compatible with NMEA *input* versions 1.5 and 2.2. However, the individual serial ports can only be programmed to use NMEA version 2.2 as an *output*.

Figure 3-15
Setting NMEA Outputs



By choosing Next or completing the configuration for each output, GyroTrac will cycle through the remaining NMEA outputs. Each output follows the same sequence of screens as illustrated in this flow chart.



When Serial Ports 2 or 3 are selected to provide NMEA output, the baud rate is automatically changed to 4800 baud from the default of 9600 baud. Serial Port 1 and its pass-through duplicate only provide 4800 baud output.

3.5.4 Choosing the Default Display

This option resets the ADCU display settings to their factory defaults (i.e., compass, 50 percent brightness).




Figure 3-21Selecting the Default Display

3.8.1 Manually Controlling the Antenna

These screens are only seen if Antenna Comm is turned ON.

In certain circumstances, it may be necessary to control the azimuth, elevation, and tracking of the TracVision G4 or TracVision G6 antenna manually, using the process illustrated in Figure 3-30. Use +/- to manually move the dish. Azimuth measurements are reported as relative to the bearing of the vessel's bow.

Figure 3-30
Manual Antenna
Control Procedure



If the system started up in Instant On mode, the following message may be displayed:






If the manual adjustment of the antenna reached the maximum rotation (720°), the antenna will rotate 360° and return to the Manual Antenna Control screens.



YES tells the antenna to begin actively tracking the set azimuth and elevation. NO leaves the antenna halted in its current position.



Congratulations!

You have selected one of the most advanced heading sensors available today. KVH® Industries' GyroTrac[™] offers stabilized heading data as well as outputs compatible with most other onboard systems, including radar and autopilot. GyroTrac also serves as the external sensor for GyroTrac-compatible TracVision® satellite television systems. This manual provides detailed instructions on the proper installation, use, and maintenance of your GyroTrac system.

Throughout this manual, important information is marked for your attention by these icons:



A helpful tip that either directs you to a related area within the manual or offers suggestions on getting the highest quality out of your system.



An alert to important information regarding procedures, product specifications, or product use.



Information about installation, maintenance, troubleshooting, or other mechanical issues.



An electrical safety warning to help identify electrical issues that can be a hazard to either this KVH product or a user.

Direct questions, comments, or suggestions to:

KVH Industries, Inc.

50 Enterprise Center Middletown, RI 02842 USA

tel: +1 401 847-3327 fax: +1 401 849-0045 e-mail: info@kvh.com

KVH Europe A/S

Ved Klaedebo 12 2970 Hoersholm Denmark tel: +45 45 16 01 80

fax: +45 45 86 70 77 e-mail: info@kvh.dk

internet: http://www.kvh.com internet: http://www.kvh.com



GyroTrac Serial Number

This serial number will be required for all troubleshooting or service calls made regarding this product.

KVH Part # 54-0142 Rev. G © 2000, KVH Industries, Inc. $\mbox{TracVision}^{\mbox{\scriptsize @}}$ and $\mbox{KVH}^{\mbox{\scriptsize @}}$ are registered trademarks of KVH Industries, Inc.

GyroTrac[™] is a trademark of KVH Industries, Inc.

Cetrek[™] is a trademark of Cetrek USA.

 $\mathsf{Furuno}^{\circledR}$ is a registered trademark of Furuno USA, Inc.

 $\mathsf{B\&G}^{\circledR}$ and $\mathsf{Halcyon}^{\circledR}$ are trademarks of Brooks and Gatehouse, Inc.

Table of Contents

1	Intro	Introduction			
1.1	Gyro1	yroTrac Overview1-1			
1.2	The GyroTrac System1-1				
1.3	Mater	rials Provided with GyroTrac	1-3		
2	Insta	llation	2-1		
2.1	Choo	sing the Best Location	2-2		
	2.1.1	Mounting on Steel Vessels	2-3		
2.2	Moun	ting the Sensor Module	2-3		
2.3	Moun	ting the ADCU	2-6		
2.4	Wiring	g the GyroTrac	2-7		
	2.4.1	Connecting the GyroTrac to External Devices	-10		
	2.4.2	GyroTrac Wiring Diagram	-10		
	2.4.3	Wiring an Optional GyroTrac-compatible TracVision System	-12		
	2.4.4	Wiring the GyroTrac Sine/Cosine Interface	-12		
	2.4.5	True North Capability	-13		
2.5	Conn	ecting to Vessel Power	-13		
2.6	Calib	rating the Sensor Module	-14		
	2.6.1	Compensating the GyroTrac	-14		
	2.6.2	The Calibration Score	-15		
2.7	Comp	oleting the Installation	-15		
3	Interf	face Configuration and Operation	3-1		
3.1	Startu	up and Self-test	3-1		
	3.1.1	TracVision Startup and Self-test Screens	3-2		
3.2	Data l	Display and Accessing the Main Menu	3-3		
	3.2.1	Main Menu	3-4		
	3.2.2	Alert Screens	3-5		
	3.2.3	System Security	3-5		

54-0142 Rev. G

	3.2.4	The RETURN and CANCEL Keys	3-6
	3.2.5	Antenna Error Messages	3-6
3.3	Setup	Display Mode	3-7
3.4	Set D	ata Outputs Mode	3-8
	3.4.1	Setting the Sine/Cosine Data Output	3-9
	3.4.2	Setting the Serial Outputs	3-10
	3.4.2.	1 Setting the NMEA Outputs	3-11
	3.4.3	Setting the Furuno Output	3-12
3.5	Set C	onfiguration Mode	3-13
	3.5.1	Setting Display Brightness	3-14
	3.5.2	Selecting Heading Reference Source	3-14
	3.5.3	Entering Gyro Offset Values	3-15
	3.5.4	Choosing the Default Display	3-16
	3.5.5	Selecting TracVision or GyroTrac-only Operations	3-16
3.6	Contr	rol Compass Mode	3-17
	3.6.1	Selecting Autocompensation	3-17
	3.6.2	Reading the Calibration Score	3-18
	3.6.3	Clearing Compass Calibration	3-18
3.7	Anter	nna Status Mode	3-19
	3.7.1	Antenna Status Data Screens	3-20
3.8	Contr	rol Antenna Mode	3-21
	3.8.1	Manually Controlling the Antenna	3-22
	3.8.2	Restarting the Antenna	3-23
	3.8.3	Turning Sleep Mode On/Off	3-23
	3.8.4	Turning Instant On Mode On/Off	3-24
	3.8.5	Installing a New Satellite Pair	3-25
	3.8.6	Setting Latitude and Longitude	3-26
	3.8.7	Selecting Active Satellite	3-27
4	Troub	oleshooting	4-1
5	Main	tenance	5-1

5.1	Warranty/Service Information				
5.2	Replaceable Parts5-1				
Appe	ndix A	System Specifications			
Appe	ndix B	Optional KVH Displays			
B.1	Option	nal Display SpecificationsB-1			
B.2	Moun	ting the Pointer Analog and Digital DisplaysB-2			
	B.2.1	Mounting the Display Backlighting ControlB-3			
	B.2.2	Wiring the Pointer Analog and Digital DisplaysB-3			
	B.2.3	Wiring the Backlight Control SwitchB-4			
B.3	Moun	ting the Rotating Card DisplayB-4			
	B.3.1	Bracket Mounting			
	B.3.2	Panel MountingqB-5			
	B.3.3	Wiring the Rotating Card Display			
Appe	ndix C	Data Outputs			
C.1	Sine/C	Cosine Output			
C.2	Serial	Port Outputs			
C.3	Furun	o Output			
	C.3.1	Optional Stepper Components			
Appe	ndix D	ADCU Flush Mount Panel Template			
Appe	ndix E	Rotating Card Display Mounting TemplatesE-1			
Temp	late E-1	Rotating Card Display Bracket MountingE-1			
Temp	late E-2	Rotating Card Display Panel Mounting E-3			
Lis	t of	Figures			
Figure	e 1-1	GyroTrac Identifies and Compensates for Vessel Motion			
Figure	e 1-2	GyroTrac Sensor Module1-1			
Figure	e 1-3	Front, Rear, and Angle View of GyroTrac ADCU1-2			

54-0142 Rev. G iii

Figure 1-4	Possible GyroTrac System Configurations1-2
Figure 1-5	GyroTrac Package Contents
Figure 2-1	Horizontal Sensor Bracket2-3
Figure 2-2	Vertical Sensor Bracket2-3
Figure 2-3	Proper Orientation of the Sensor Module2-4
Figure 2-4	Securing the Sensor Module and the Horizontal Sensor Bracket
Figure 2-5	Optional Bracket Orientations
Figure 2-5a	Attaching the Horizontal and Vertical Brackets2-5
Figure 2-6	Mounting the ADCU with Velcro Attachments2-6
Figure 2-7	Securing the ADCU to the Flush Mount Bracket2-7
Figure 2-8	Terminal Strip Order
Figure 2-9	Attaching the Terminal Strips to the ADCU2-8
Figure 2-10	Examples of Effective Strain Relief Arrangements 2-9
Figure 2-11	Proper Wiring for Connectors 1-36 (GyroTrac)2-11
Figure 2-12	Sample Calibration Score Screen
Figure 3-1	Startup and Self-test
Figure 3-2	Startup Error Screen
Figure 3-3	GyroTrac Startup Screens3-2
Figure 3-4	Soft Key Functions and Main Data Displays3-3
Figure 3-5	Main Menu Functions
Figure 3-6	Sample Alert Screens
Figure 3-7	PIN Code Screens
Figure 3-8	Erase PIN Code Screen
Figure 3-9	Incorrect Response Error Message
Figure 3-10	Non-responsive Antenna Error Message
Figure 3-11	Setting Display
Figure 3-12	Data Outputs Mode Menu Sequence3-8
Figure 3-13	Setting Sine/Cosine Data Output3-9
Figure 3-14	Setting Serial Outputs
Figure 3-15	Setting NMEA Outputs
Figure 3-16	Setting Furuno Output3-12

Figure 3-17	Configuration Mode Menu Sequence	3-13
Figure 3-18	Display Brightness Controls	3-14
Figure 3-19	Internal/External Reference Menus	3-14
Figure 3-20	Entering Gyro Offset Values	3-15
Figure 3-21	Selecting the Default Display	3-16
Figure 3-22	Selecting TracVision- or GyroTrac-only Operations	3-16
Figure 3-23	Compass Control Mode Menu Sequence	3-17
Figure 3-24	Setting Autocompensation	3-17
Figure 3-25	Reading the Calibration Score	3-18
Figure 3-26	Clearing Compass Calibration	3-18
Figure 3-27	Antenna Status Mode Menu Sequence	3-19
Figure 3-28	Antenna Status Data Screens	3-20
Figure 3-29	Control Antenna Mode Menu Sequence	3-21
Figure 3-30	Manual Antenna Control Procedure	3-22
Figure 3-31	Restart Antenna Menu	3-23
Figure 3-32	Sleep Mode Menu	3-23
Figure 3-33	Instant On Mode Menu	3-24
Figure 3-34	Installing Satellite Pair Process	3-25
Figure 3-35	Set Latitude/Longitude Procedure	3-26
Figure 3-36	Select Active Satellite	3-27
Figure 4-1	ADCU Fuse Location (Top Cover Cut Away)	4-1
Figure 5-1	Data Cable Terminal Arrangement	5-2
Figure B-1	Display Options	B-1
Figure B-2	Mounting the Analog/Digital Displays	B-2
Figure B-3	Mounting the Display Backlighting Control Switch	B-3
Figure B-4	Wiring the Backlight Control Switch	B-4
Figure B-5	Rotating Card Display – Removing the Backplate	B-5
Figure B-6	Rotating Card Display – Terminal Strip Wiring	B-6
Figure B-7	Rotating Card Display – PC Board Jumpers	5.6
Figure 0.4	and Connectors	
FIGURA (C-1	Stenner Interface	C-4

54-0142 Rev. G

Figure C-2	Optional 6-70v Stepper Voltage Converter Wiring Diagram
List of	Tables
Table 1-1	GyroTrac Packing List
Table 2-1	Recommended Power Cable Specifications
Table 2-2	Kitpack Contents
Table 2-3	GyroTrac/Autopilot Sine/Cosine Wiring Arrangement2-12
Table 2-4	GyroTrac Power Requirements2-13
Table 2-5	Possible Compass Accuracy Levels2-15
Table 5-1	Field Replaceable Units5-2
Table 5-2	Data Cable Wiring/Terminal Assignments5-2
Table A-1	System Performance
Table A-2	Environmental Specifications
Table A-3	Interface Assignments
Table B-1	Display Specifications
Table B-2	Display Cable Connections
Table B-3	Rotating Card Display – Terminal Strip Wiring Details
Table C-1	NMEA1 Magnetic Heading Output
Table C-2	NMEA2 Magnetic Heading Output
Table C-3	NMEA3 True Heading Output
Table C-4	KVH Output
Table C-5	Cetrek Output
Table C-6	Stepper Interface Specifications



Color quick reference guides for GyroTrac wiring and menus have been provided on the inside front cover of this manual.

1 Introduction

1.1 GyroTrac Overview

Your KVH GyroTrac is designed for a variety of applications where an extremely accurate and reliable stabilized heading output is required. This means that the heading output is free of incidental movement by the host platform such as the pitch, roll, and yaw inherent in all dynamic applications. GyroTrac, in fact, eliminates all platform motion except actual changes in magnetic heading. It does this by measuring pitch, roll, and yaw with its gyroscope, digital compass, and inclinometer and correcting for these values in its microprocessor, effectively removing them. The result is accurate, drift-free heading output.

Although GyroTrac can be used as a stand-alone heading sensor, it can also be integrated with other equipment, including radars, autopilots, plotting systems, and computers. It is also fully compatible with the KVH TracVision® 3, TracVision G4, and TracVision G6 stabilized satellite TV systems. Its autocompensation feature measures local magnetic field distortion and removes it, giving better than $\pm 1^{\circ}$ accuracy even on steel vessels, when mounted correctly.

Heading output is available as standard NMEA 0183 (HDT, HDM, or HDG), KVH heading, pitch, roll, and Cetrek[™], plus user-configurable sine/cosine or B&G 4-wire sine/cosine, and Furuno[®] AD10S. A stepper unit (KVH Part Number 19-0078) is available as an optional interface module. True north output is available by interfacing with a GPS.

1.2 The GyroTrac System

GyroTrac consists of two key components: the Sensor Module and the Advanced Digital Control Unit (ADCU).

Sensor Module

The Sensor Module serves as the system's compass, housing the yaw sensor, inclinometer, rate gyros, and processing electronics. The Sensor Module is compliant with the IP67 standard, making the unit waterproof to a depth of 1 meter. The sensor module may be mounted above decks if desired.

Figure 1-1
GyroTrac Identifies and
Compensates for Vessel Motion




Figure 1-2GyroTrac Sensor Module




54-0142 Rev. G 1-1

Advanced Digital Control Unit (ADCU)

The ADCU is the user interface, providing access to the system and its functions through the LCD and three soft keys beneath it. The ADCU also serves as the system's junction box, allowing the system to use ship's power, interface with the Sensor Module, supply and receive data to and from a GyroTrac-compatible TracVision system, and supply and receive data from other shipboard systems.

Figure 1-3 Front, Rear, and Angle View of GyroTrac ADCU






The system is designed to interface with additional onboard equipment, as illustrated in Figure 1-4.

Figure 1-4Possible GyroTrac System
Configurations



If a GyroTrac-compatible TracVision system is connected to GyroTrac, the power supply to the TracVision MUST NOT exceed 16V or the TracVision power supply will suffer serious damage!



1.3 Materials Provided with GyroTrac

When you open your GyroTrac package, in addition to the cables and kitpack, you will find these components:

Table 1-1 lists the units, cables, and materials packed in the GyroTrac package by name and KVH part number.




Figure 1-5
GyroTrac Package Contents

Component	KVH Part No.		
Sensor Module	02-0991		
ADCU	02-0961		
Flush Mount ADCU Panel	20-0667		
Horizontal Sensor Bracket	20-0658		
Vertical Sensor Bracket	20-0666		
Sensor to ADCU Cable (30 ft.)	32-0623-30		
Kitpack*	72-0095		

Table 1-1GyroTrac Packing List

54-0142 Rev. G 1-3

 $^{^{\}star}$ A complete list of the kitpack contents is provided in Section 2, "Installation."

2 Installation

GyroTrac is designed for simple installation and setup. Just follow these easy steps:

- 1. The serial number of your GyroTrac will be required during any service or troubleshooting calls. The serial number is on the inside front cover of this manual, on the Sensor Module end cap, and on the back of the ADCU. The serial number for both components is the same.
- 2. Choose locations for the Sensor Module and ADCU.
- 3. Mount the Sensor Module.
- 4. Mount the ADCU.
- 5. Wire components together, to ship's DC system, and to onboard systems as appropriate.
- 6. Calibrate the sensor.

Recommended Tools and Materials

- Electric drill, assorted drill bits
- Light hammer; center punch; adhesive tape; scriber or pencil
- Phillips (long shank) and flat tip screwdrivers
- Wire strippers
- Power cable to connect ADCU to ship's power

Recommended Power Cabling

The following cable sizes are recommended for the specified running lengths and are based on Lloyd's and ABYC specifications. Cable jacketing should meet marine insulation standards while the cable should be tinned, stranded marine stock.

Cable Length	Cable Gauge
to 50 ft (15 m)	14 AWG (1 mm ²)
50-80 ft (25 m)	12 AWG (1.5 mm ²)
+80 ft (+25 m)	10 AWG (2.5 mm ²)



Plan the entire installation before proceeding! Take into account component placement, running cable distances between units and accessibility to the equipment after installation.

Table 2-1Recommended Power Cable
Specifications

54-0142 Rev. G 2-1

Kitpack

Table 2-2 lists the materials provided in the GyroTrac kitpack.

Table 2-2Kitpack Contents

Part	Qty.	KVH Part No.
#8 Fiber Washer	10	14-0239
#8 Flat Washer	10	14-0037
#8 Self-locking Nut	5	14-0065-08
#8 Pan (Phillips head) Screw	5	14-0041-06
#10 Flat Washer	5	14-0048
#10 Lock Washer	5	14-0049
#10 Pan (Phillips head) Screw	5	14-0051-03
#8 Pan (Phillips head) Screw	5	14-0243-05
#8 Lock Washer	5	14-0038
#8 Pan (Phillips head) Screw BP	5	14-0047-08
Velcro Self-Adhesive Backing	8	19-0146
Velcro Washer	4	19-0147
4" Tie-wrap Clamp	5	22-0013
Tie-wrap Screw Mount	6	22-0038
Connector Wire Terminal Strip	5	23-0223-12
Sensor Module to ADCU Power Wire Ferrite	1	29-0037-02

2.1 Choosing the Best Location

Ideally, the GyroTrac sensor module should be mounted as low as possible in the center of the vessel – but *NOT* in the bilges.

- Place the Sensor Module as far as practical (minimum 3 ft./0.9 m) from magnetized or magnetizable materials.
- Maintain at least 4 feet (1.3 m) separation between the Sensor Module and any large ferrous masses, cables carrying high amperage direct current, or battery banks.
- Be alert for devices that change their magnetic characteristics when in use, such as CRTs, computer and TV screens, radar magnetrons, electric winches, loudspeakers, windshield wipers,



Be certain to isolate the Sensor Module from ground (i.e., the ship's hull) by always using the fiber washers when attaching the Horizontal Sensor Bracket to either a mounting surface or the Vertical Sensor Bracket.

- and other devices with DC motors. GyroTrac cannot compensate for changing magnetic fields created by these devices.
- Ensure that the ADCU is located within the running cable distance (30 ft./9.2 m) of the Sensor Module.
- If necessary to fabricate custom mounting brackets for the Sensor Module, they should be made from non-ferrous materials such as wood, brass, aluminum, fiberglass, or plastic.

2.1.1 Mounting on Steel Vessels

The GyroTrac sensor module is a digital magnetic compass and great care is required when positioning the unit on steel-hulled craft. The ideal location is in the wheelhouse or above decks. Mount on an aluminum pole or bracket, well away from magnetic fields such as cranes, derricks, motors, radomes, antennas, etc.

DO NOT mount the sensor module on a steel or iron platform. Use aluminum, brass, plastic, or wood.

2.2 Mounting the Sensor Module

GyroTrac's Sensor Module comes equipped with two mounting brackets. The first is the Horizontal Sensor Bracket, which attaches directly to the Sensor Module housing, and must be used in all mounting arrangements.

The Vertical Sensor Bracket allows the Sensor Module to be mounted on a vertical surface. The following steps detail the correct use of each bracket.

These brackets should enable the Sensor Module to be placed as level in pitch and roll as possible. If you are unable to place the Sensor Module in a level arrangement, refer to *Section 3.5.3, "Entering Gyro Offset Values"* to compensate.



If uncertain of the best location for the sensor module, make a temporary installation and conduct a compass calibration (as described in Section 2.6, "Calibrating the Sensor Module.") Any necessary adjustments to the sensor location can be made based on the calibration scores.

Figure 2-1Horizontal Sensor Bracket






Figure 2-2 Vertical Sensor Bracket



54-0142 Rev. G 2-3

Figure 2-3

Proper Orientation of the Sensor Module






Should you ever need to replace the #10 machine screws used to secure the housing and bracket, the screws must be no longer than 3/8" to avoid damaging the housing.

Figure 2-4

Securing the Sensor Module and the Horizontal Sensor Bracket

Horizontal Bracket Only

- 1. Choose a mounting location free of excessive vibration and flexing.
- 2. The module must be oriented so that the forward reference on the end cap is pointed forward and parallel to the vessel's fore-and-aft axis (to $\pm 5^{\circ}$). The proper orientation is illustrated in Figure 2-3.
- 3. Position the Horizontal Sensor Bracket so that the Sensor Module will be properly oriented when placed in the bracket.
- 4. Use the holes in the bracket feet to spot for mounting screws. Center punch and drill 4 holes with a 1/8" (0.125" or 3.5 mm) bit.
- 5. As illustrated in Figure 2-4, position the bracket over the mounting holes.
 - Insert fiber washers into both sides of mounting bracket.
 - Insert #8 flat washers and #8 pan head screws into the holes.
- 6. Place the Sensor Module in the bracket with the proper orientation (up/forward).
- 7. Thread #10 machine screws through lock washers, flat washers, and bracket, and then into the captive extrusion T-nuts within the Sensor Module housing as illustrated in Figure 2-4.



Step 5. Insert fiber washers on both sides and secure bracket to mounting site

Horizontal and Vertical Bracket

- 1. Choose a mounting location free of excessive vibration and flexing.
- 2. The module must be oriented so that the forward reference on the end cap is pointed forward and parallel to the vessel's fore-and-aft axis. See Figure 2-3 for reference. The brackets are designed so that the Sensor Module may be mounted perpendicular (option 1) or parallel (option 2) to the mounting surface.
- 3. The module must be level with the vessel's deck. This placement can be fine tuned by using the ADCU pitch and roll data. Adjust the brackets so that the pitch and roll are 0 (zero) when the vessel is docked and under normal load.
- 4. When choosing a location for the unit, make certain that there is sufficient overhead clearance for both brackets *and* the Sensor Module.
- 5. Use the holes in the Vertical Sensor Bracket to spot for mounting screws. Center punch and drill 4 holes with a 1/8" (0.125" or 3.5 mm) bit.
- 6. Secure the Vertical Sensor Bracket to the vertical surface with #8 flat washer and #8 screws.
- 7. Attach the Horizontal Sensor Bracket to the Vertical Sensor Bracket as shown in Figure 2-5a.
 - Position the Horizontal Sensor Bracket over the mounting holes in the Vertical Sensor Bracket.
 - Insert fiber washers into both sides of mounting bracket.
 - Insert #8 flat washers and #8 pan head screws into the holes.
- 8. Place the Sensor Module in the bracket with the proper orientation (up/forward).
- 9. Thread #10 machine screws through lock washers, flat washers, and bracket, and then into the captive extrusion T-nuts within the Sensor Module housing.

Figure 2-5Optional Bracket Orientations





Figure 2-5aAttaching the Horizontal and Vertical Brackets



54-0142 Rev. G 2-5



When choosing a location, be certain to take into account the space required to route, position, and strain relieve all cables that will be attached to the back of the ADCU. Directions for proper wiring are presented in Section 2.4, "Wiring the GyroTrac."

2.3 Mounting the ADCU

The ADCU may be mounted in one of two ways: either directly to a horizontal surface using Velcro fasteners or flush to a control panel. Both the fasteners and the Flush Mount Bracket are included as part of the GyroTrac package.


Some tips for installing the ADCU:

- The ADCU should be placed in a dry location that is convenient for the user.
- It is not susceptible to magnetic interference nor must it be situated on a level surface.
- It should be placed so the LCD display is visible and push buttons are accessible.
- Allow room at the back to connect cables to the rear panel.

Velcro Fastening

- 1. Choose a flat, stable location.
- 2. Remove the two strips of velcro fabric from the kitpack. Clean the bottom of the housing with a mild detergent and water to remove oils, etc. Peel the protective backing from the strips and apply them to the bottom of the housing at each of the four corners.
- 3. Position the four hook disks where the ADCU will be mounted. Drill screw holes for the disks and attach. Press the ADCU firmly into place so the loop material engages the hook disks.

Figure 2-6
Mounting the ADCU with
Velcro Attachments



Flush-mounting the ADCU

- 1. A template has been provided in Appendix D as a guide to mark and cut the proper hole for the Flush Mount Bracket. Cut the hole and make certain the bracket and ADCU will fit easily.
- 2. Attach the Flush Mount Bracket to the ADCU by loosening the two screws on the underside of the ADCU. Slide the Flush Mount Bracket backward over the ADCU until the two notches meet the screws as shown in Figure 2-7.





Figure 2-7
Securing the ADCU to the Flush
Mount Bracket

- 3. Tighten the screws to secure the ADCU to the bracket.
- 4. After completing the wiring described in *Section 2.4, "Wiring the GyroTrac,"* insert the ADCU and bracket into the hole and secure the unit.

2.4 Wiring the GyroTrac

All wiring for the GyroTrac connects at the rear panel of the ADCU. Included in the GyroTrac kitpack are five terminal strips with terminal connectors numbered 1 through 60 (Figure 2-8 on the following page).

Figure 2-8 Terminal Strip Order




After wires are secured within the terminal connectors, the strips will be slotted into the rear panel of the ADCU as illustrated in Figure 2-9.

Figure 2-9Attaching the Terminal Strips to the ADCU



Double-check all wiring. Be certain to plug terminal strips into the correct positions. If wiring is incomplete or incorrect or the terminal strips exchange positions, serious electrical damage can occur to the GyroTrac system and interfacing electronics.



Tips for Successful and Safe Wiring


- When inserting a wire into the terminal connector, make certain wire insulation is not pinched in the connector.
- After inserting and securing wire, tug gently to ensure that the connection is solid.
- Position cables behind ADCU so that they connect neatly to the terminal strips.
- Do not tin (solder) the wire ends.

Effective Strain Relief for ADCU Terminal Connections

Due to both the potential number of wires that will be connecting to the rear of the ADCU and the dynamic environment aboard ship, it is critical that the terminal connections are properly strain relieved using tie-wraps (a number of which are included with the GyroTrac kitpack).

Some things to consider when strain relieving cables:

- There should be no tension on the wires connecting to the terminal strip. Removing slack is important but the wires should not be taut.
- If the cable is equipped with a ferrite, the ferrite should be as close as possible to the terminal connections.
- Strain relieve wires and cables as close to the ferrite as possible. A good arrangement includes a tie-wrap behind the ferrite (on the side furthest from the ADCU); an ideal design includes a tiewrap on either side of the ferrite.





If the GyroTrac is receiving data from a ship's gyro, all compass outputs are automatically configured as True North and cannot be set as Magnetic.



Section 3, "Interface Configuration and Operation," presents details on configuring GyroTrac's serial ports to meet the output requirements of a variety of additional equipment.



A color GyroTrac wiring quick reference guide has been provided on the front cover of this manual.

2.4.1 Connecting the GyroTrac to External Devices

All connections between the GyroTrac and external devices are made at the connector strips located on the rear of the ADCU. Follow these guidelines when wiring the GyroTrac to additional equipment:

- Make certain any additional equipment complies with NMEA Standard 2.2.
- Data conductor wire should be minimum 18 AWG (0.75 mm²), twisted pair, stranded, tinned marine cable.
- Do not use cables with wire diameter larger than 12 AWG (2.5 mm²), as the connector plugs on the rear of the ADCU accept wire no larger than 12 AWG (2.5 mm²) size.
- Cables provided with optional KVH displays and interface units are fully compatible with GyroTrac requirements. Note that cables to other external devices should follow the manufacturer's recommendations.
- For power cable specifications, refer to Table 2-1 at the beginning of this section.

Appendix B provides instructions on properly wiring optional KVH equipment to the GyroTrac system.

2.4.2 GyroTrac Wiring Diagram

Figure 2-11 on the following page presents a complete wiring diagram for each GyroTrac terminal connector strip.

Figure 2-11

Proper Wiring for Connectors 1-36 (*GyroTrac*) Green Label 2 3 4 5 6 7 8 9 10 11 12 SHIP'S POWER Power In (Red) _ _ Sine (see Table 2-3, GyroTrac _ Sine (inverted) Ground In (Black)_ Power Requirements) SINE/COSINE _ _ Cosine KVH Display Power - - -(3-wire or 4-wire) Cosine (inverted) Refer to Section 2.4.4 SERIAL PORT #1: RS-422 TX1A(+) _ _ for complete intructions (NMEA, Cetrek, KVH Data) TX1B(-) _ _ _ | 4800 baud Ground _ _ _ I 1---Blue Label 13 14 15 16 17 18 19 20 21 22 23 24 GPS or SHIP'S GYRO Ground (White/Green) _ _ _ GPS A+ NMEA DATA INPUT _ _ GPS B-TX(+) (White/Blue) _ _ _ | (RS-422 @ 4800 bps 8.N.1) GYROTRAC TX(-) (Blue/White) - -_ _ KVH Display Power SENSOR MODULE RX(-) (White/Orange) _ _ Pass-through Duplicate of _ _ TX1A(+) Cable #32-0623-30 SERIAL PORT #1: RS-422 RX(+) (Orange/White) _ _ _ _ TX1B(-) 4800 baud +12v (Green/White) _ _ _ | White Label 25 26 27 28 29 30 31 32 33 34 35 36 SERIAL PORT #3: RS-422 (NMEA, Cetrek, KVH Data) TX3B(-) _ _ _ | _ _ _ Data L 4800 or 9600 baud Unavailable with TracVision ı _ _ _ Ground TX3A(+) - -**FURUNO** To modify, refer to Section 3.5.4 DATA _ _ Shift H SERIAL PORT #2: RS-422 _ Shift L (NMEA, Cetrek, KVH Data) TX2B(-) _ 4800 or 9600 baud Ground TX2A(+) _ _ _ |

As noted in Figure 2-11, the output for Serial Ports 2 and 3 can vary from 4800 baud to 9600 baud. This is determined automatically based upon the selected output. Serial Port 1 provides 4800 baud output only.



When a TracVision antenna is connected to a GyroTrac system, Serial Port 3 will not provide output to other equipment. To restore Serial Port 3 operation, GyroTrac needs to be reconfigured for GyroTrac-only operation. Refer to Section 3.5.5, "Selecting TracVision or GyroTrac-only Operations."

2.4.3 Wiring an Optional GyroTrac-compatible TracVision System

The GyroTrac-compatible TracVision satellite TV system connects directly to the ADCU via the top two terminal connector strips. Refer to the appropriate TracVision user manual for complete instructions for wiring a GyroTrac-compatible TracVision system to the ADCU.

2.4.4 Wiring the GyroTrac Sine/Cosine Interface

The GyroTrac sine / cosine interface provides the following outputs:

- sine
- cosine
- inverse sine
- inverse cosine
- reference voltage

Because the reference voltage is a reference output, not an input, connecting this output to another reference output from an autopilot or other system will cause problems.

In this case, connect the following wires from the autopilot (or other system) to the GyroTrac:

4

The sine/cosine reference voltage is an OUTPUT, not an INPUT.
Connecting this output to the reference output for an autopilot or other system can result in problems. Section 2.4.4 provides instructions on how to solve this problem.

Table 2-3GyroTrac/Autopilot Sine/Cosine
Wiring Arrangement



Before connecting the Autopilot internal ground to ADCU terminal 7, use a low impedance voltmeter to make certain that there is no DC voltage between the two terminals. A DC surge could damage one or both systems.

Autopilot/Other System Wire	ADCU Terminal		
Sine	12		
Cosine	10		
Internal Power Ground (not chassis ground!)	7		
Reference (INPUT)	8 (KVH Output)		

DO NOT connect the autopilot or other system to the GyroTrac reference output (ADCU terminal 8) if the autopilot has its own internal reference. Review the user's manual for the selected equipment.

To adjust the GyroTrac reference to match the reference of the autopilot (or other system), connect a voltmeter to GyroTrac ADCU terminal (#8) and the reference terminal of the autopilot

(or other system). Adjust the GyroTrac reference voltage as described in *Section 3.4.1, Setting the Sine/Cosine Data Output,* until the voltmeter indicates 0 VDC.

The sine/cosine interface should now operate with optimal precision.

2.4.5 True North Capability

GyroTrac is capable of determining true north that is accurate, under most conditions, to within $\pm 1.0^{\circ}$. This information is obtained by providing GPS data input and reading the magnetic variance tables.

NMEA sentences from the GPS must contain one or all of the following sentences: VTG, VHW, or BWC. The sentence structure must comply with the NMEA 0183 V2.20 standard and run at 4800 bps 8.N.1.

As illustrated in Figure 2-11 and the quick reference guide on the cover of this manual, GPS interface cables connect to the ADCU at terminals 23 and 24. Refer to your GPS user manual for the correct NMEA data out configuration.

2.5 Connecting to Vessel Power

Short circuits may result in severe electrical shock or burns. Turn off vessel power and test the circuit to ensure that no power is present before connecting the power cable.

The power needs of the GyroTrac vary based on its use as either a standalone system or as a component of a GyroTrac-compatible TracVision system:

GyroTrac Function	Power Requirement		
As GyroTrac System	12-32V DC		
As Sensor for TracVision	11-16V DC		

The GyroTrac system does not have a dedicated power control (ON/OFF switch). A quick-tripping circuit breaker or fuse should be installed between vessel power and the ADCU. Circuit overload protection should be rated for 5 amperes. For recommended power cable specifications, refer to Table 2-1 at the beginning of this section.



When the vessel is stationary, certain GPS models may not output the data required for GyroTrac to determine true north.



If a GyroTrac-compatible TracVision system is connected to GyroTrac, the power supply to the TracVision MUST NOT exceed 16V or the TracVision power supply will suffer serious damage!

Table 2-4GyroTrac Power Requirements



The ADCU is equipped with a 1-amp fuse to protect against high-voltage spikes. If the system is installed correctly and power is available, but the system is non-functional, refer to Section 4, "Troubleshooting," for instructions on checking and replacing the fuse.



You must compensate the GyroTrac Sensor Module after installation so that any errors due to metal and magnetism in your vessel are removed!



A complete explanation of the GyroTrac menus is provided in Section 3, "Interface Configuration and Operation." Specifics regarding calibration are in Section 3.6, "Control Compass Mode."

If vessel power fluctuates widely or is noisy, a wide-range DC/DC converter power supply should be installed. *Test the voltage and polarity before making connections to vessel power.*

If the user-supplied power cable has a drain or shielded wire, *do not* connect the drain or shield to either the ADCU or to ground.

2.6 Calibrating the Sensor Module

Although every Sensor Module is calibrated at the factory, hard and soft iron effects on the host platform can distort the local magnetic field, causing errors in the reported heading. These errors are minimized by proper location of the Sensor Module and are further removed by GyroTrac's autocompensation feature, which measures the surrounding magnetic field distortions and compensates for them, thereby removing the resulting heading errors and giving you a system with better than ±1° accuracy in most cases.

It is critical that the compensation procedure be performed and a good calibration score be achieved following GyroTrac's installation. This will ensure the accuracy of GyroTrac's measurements and the data it provides to your other onboard systems. Failure to properly calibrate the system may result in an autocalibration conducted under less-than-ideal circumstances. To ensure that some form of calibration occurs after installation, GyroTrac leaves the factory with its autocompensation feature turned on because any compensation is better than none. Autocompensation will automatically shut off if a Calibration Accuracy of <8° or better is recorded. However, <8° accuracy is insufficient for precision heading measurements. KVH recommends that you follow the procedure outlined in the following sections to ensure that your system is calibrated properly.

2.6.1 Compensating the GyroTrac

Select a calm day and a clear area. Avoid excessive pitching and rolling, as this can distort the compensation data.

- 1. Apply power to the GyroTrac and note your approximate heading so that you will know when you have completed a full circle.
- 2. Set the rudder to steer your boat at a slow, steady speed through a full circle that takes at least 2 minutes to complete. (Try to time your turn so

that it takes 30 seconds or more to turn 90°.) After completing a full circle, continue the process with a second circle. The circles do not need to be perfectly round as long as you make a complete 360° turn.

3. Once you have completed two full circles, your compass should be compensated. Check the calibration score as described in the next section.

2.6.2 The Calibration Score

Each compensation results in a calibration score, pictured in Figure 2-12, that is stored in the system's memory.

ACC (Calibration Accuracy)

The ACC data indicates the degree of accuracy the GyroTrac will provide based on the quality of the last calibration. Table 2-5 lists the five possible accuracy levels.

MAGENV (Magnetic Environment)

The MAGENV score (GOOD, OK, POOR, BAD) indicates the quality of the installation location. If the quality is POOR or BAD, the Sensor Module probably should be moved to a more favorable magnetic environment.

CAL # (Calibration Update Number)

The CAL # indicates the number of times the deviation table has been updated. It is used primarily to verify whether a new calibration has been accepted by the system.

2.7 Completing the Installation

The physical installation of GyroTrac is now complete. *Section 3, Interface Configuration and Operation,"* provides detailed instructions on defining GyroTrac's operations and outputs.

Figure 2-12Sample Calibration Score Screen



Table 2-5Possible Compass Accuracy Levels

ACC Score	Accuracy		
<1°	Better than 1°		
<2°	Better than 2°		
<4°	Better than 4°		
<8°	Better than 8°		
BAD CAL	Recalibrate		
	*		




Be certain to fill out and return the warranty card to KVH.

3 Interface Configuration and Operation

All operations related to TracVision antennas and GyroTrac are controlled and monitored using the ADCU. An LCD screen displays navigation and configuration data and three soft keys enable a user to perform a multitude of menu-driven tasks.

3.1 Startup and Self-test

- 1. Turn on the IRD and the television receiver.
- 2. If a GPS receiver is connected, ensure that it has obtained an accurate position.
- 3. Apply operating power to the ADCU.
- 4. Wait while system conducts brief self-test sequence. Test status messages are displayed on the ADCU for approximately two seconds each.





A number of antenna-specific screens will only be available on the interface if a GyroTraccompatible system is connected to the ADCU. Due to operational differences between TracVision 3, TracVision G4, and TracVision G6, certain screens will only be available when the appropriate system is connected to the ADCU. These screens are identified throughout this section.

Figure 3-1
Startup and Self-test



The absence of valid GPS data is not a fault; the status message simply indicates that GPS data is not present, and that those navigation functions that use GPS inputs are not available.

Figure 3-2Startup Error Screen




If the self-testing routine detects faults in any of the first four self-tests, the screen pictured in Figure 3-2 is displayed. Operation halts at this point and the GyroTrac cannot operate. The unit should be returned to your local authorized KVH dealer, distributor, or service center.

3.1.1 TracVision Startup and Self-test Screens

When configured as a component of a TracVision system, GyroTrac conducts a series of startup routines and self-tests to verify antenna operation. The TracVision self-test status screens are *only* displayed when the main data display is set to show the antenna status information (as described in *Section 3.3, "Setup Display Mode"*).

Figure 3-3 GyroTrac Startup Screens



3.2 Data Display and Accessing the Main Menu

As soon as the self-test routine is completed, the LCD panel shows one of five data displays selected in the Display Setup Mode (described in *Section 3.3, "Setup Display Mode"*). When any of the primary data displays are on screen, the soft keys allow you to switch between the two installed satellites (if GyroTrac is connected to a TracVision G4 or TracVision G6) as well as enter the Main Menu mode. The key functions and display options are as follows:





Figure 3-4
Soft Key Functions and
Main Data Displays

3.2.1 Main Menu

Pressing the center key will cycle the Main Menu through the available functions as follows:



3.2.2 Alert Screens

Certain operations require GyroTrac to temporarily cease its data output or alter its configuration so that new parameters or configurations may be entered. When you enter one of these functions, a pair of alert screens will appear, informing you of what will happen. Selecting "Yes" will allow you to continue into the function. Selecting "No" will return you to the Main Menu.







Figure 3-6Sample Alert Screens

3.2.3 System Security

To prevent unauthorized adjustments to certain GyroTrac settings, certain functions require the entry of a customizable 4-digit Personal Identification Number (PIN). PIN entry and selection procedures are illustrated below. The default setting for the PIN is four zeros (0000). If an incorrect PIN is entered, the system automatically returns to the main data display.







Figure 3-7PIN Code Screens

To reset the PIN to four zeros (0000), press and hold the middle key during power-up until the Erase Pin Code screen pictured in Figure 3-8 appears.

Figure 3-8Erase PIN Code Screen



3.2.4 The RETURN and CANCEL Keys

Throughout the GyroTrac menus, the right-hand key will often be designated as either RETURN or CANCEL. These options have the following functions:

- **RETURN** Returns to the main data display. If no keys are pressed within 10 seconds, the menu will automatically default to the main data display.
- CANCEL Cancels current action and returns to the start of the action without making any changes.

3.2.5 Antenna Error Messages

At times, the ADCU will display error messages alerting you to a specific problem (e.g., you have selected an invalid satellite pair). There are also two general antenna error messages that are not related to a specific action.

"Antenna Response Incorrect" (pictured in Figure 3-9) indicates that the ADCU received an incorrect answer from the antenna in response to a request. The solution to this error is simply to carry out your requested operation again.

"Antenna not Responding" (pictured in Figure 3-10) indicates that no messages are being received from the antenna. This is usually the result of the antenna not being powered up or the antenna being unplugged from the ADCU.

Figure 3-9 Incorrect Response Error Message





Figure 3-10Non-responsive Antenna
Error Message



3.3 Setup Display Mode

The Setup Display mode selects the data that will be displayed on the ADCU LCD after startup and self-test; it does not control the data sent to remote heading display units, north-up radars, autopilots, etc.




3.4 Set Data Outputs Mode

The Set Data Outputs function is used to select several types of data formats available in the GyroTrac. The message formats are:

- 1 Sine/cosine (either 3-wire or B&G 4-wire)
- 3 serial message formats:
 - NMEA 0183
 - KVH pitch, roll, and yaw, and
 - Cetrek
- 1 Furuno AD10S

Figure 3-12Data Outputs Mode
Menu Sequence

These messages are output to displays and external navigation systems only if selected at the User Interface. Selection procedures are presented in the following sections.



3.4.1 Setting the Sine/Cosine Data Output

The sine/cosine setup is done in three stages: first the magnetic or true heading option is selected, then the reference voltage is set, and finally the swing voltage is set. The valid range for reference and swing voltages is between 0 and 6.5 volts. The default values for reference and swing voltages are 5.0 volts. Refer to your autopilot manual for correct voltage requirements.






Figure 3-13
Setting Sine/Cosine Data Output



If the GyroTrac is receiving data from a ship's gyro, all compass outputs are automatically configured as True North and cannot be set as Magnetic. If this is the case, the following variation on the magnetic/true selection screen will be displayed:



If the system is NOT connected to a GPS or a ship's gyro, only magnetic heading data will be available and the following variation on the magnetic/true selection screen will be displayed:




The system will then proceed to the "Set Ref" screens.

3.4.2 Setting the Serial Outputs

The GyroTrac can output up to three serial messages simultaneously in any combination of NMEA version 2.2, KVH RS-422, or Cetrek proprietary format. NMEA message options and the KVH and Cetrek formats are described briefly in *Appendix C*. Follow the procedures illustrated below to set the serial outputs. The factory default speed setting is 10 Hz.

Figure 3-14 Setting Serial Outputs



3.4.2.1 **Setting the NMEA Outputs**

GyroTrac is fully compatible with NMEA input versions 1.5 and 2.2. However, the individual serial ports can only be programmed to use NMEA version 2.2 as an output.



Custom configurations are not available on GyroTrac at this time.

select output BWC? Next cance: Return to 3.4.2 "Setting the Serial Outputs" By choosing "Next" or completing the configuration for each output, GyroTrac will cycle through the remaining NMEA outputs in the following order: GGA - GLL - HDG - HDM - HDT - VTG - XTE select NMEA Version Each output follows the same sequence of ReV 2.2 custom screens as illustrated in this flow chart. selection done customization not available Please Wait ** setting set to NMEA ROV. 2.2 selection done Please Wait setup output GGA? Next cancei Return to 3.4.2

Figure 3-15 Setting NMEA Outputs

By choosing "Next" or completing the configuration for each output, GyroTrac will cycle through the remaining NMEA outputs. Each output follows the same sequence of screens as illustrated in this flow chart.

When Serial Ports 2 or 3 are selected to provide NMEA output, the baud rate is automatically changed to 4800 baud from the default of 9600 baud. Serial Port 1 and its pass-through duplicate only provide 4800 baud output.

54-0142 Rev. G 3-11

"Setting the Serial Outputs"


3.4.3 Setting the Furuno Output

This option selects two available options for the Furuno output: magnetic or true heading reference and 25 millisecond or 200 millisecond data output rate.


Figure 3-16Setting Furuno Output



If the system is NOT connected to a GPS or a ship's gyro, only magnetic heading data will be available and the following variation on the magnetic/true selection screen will be displayed:




The system will then proceed to the "Set Data Rate" screen.



3.5 Set Configuration Mode


The Set Configuration function is used to select an internal or external source for heading data, enter offset values that correct for mechanical mounting alignment errors, reset the system to its factory defaults, and turn TV communications on/off.



3.5.1 Setting Display Brightness

The ADCU display's brightness may be adjusted to suit your preferences. Press the right key to make the display brighter, the left key to make it dimmer. When you are satisfied with the setting, press the center key to accept the setting.

Figure 3-18 Display Brightness Controls




3.5.2 Selecting Heading Reference Source

The Heading Reference Source menu provides the option to override the GyroTrac's external sensor module in favor of another source, such as a ship's gyro, as follows:

- **INTERNAL** GyroTrac will receive and use heading data from its sensor module. In addition, the Control Compass menus will be available.
- **EXTERNAL** GyroTrac will receive and use heading data from an external heading source. As a result, the Control Compass menus will be inactive and hidden. Refer to Figure 2-18 for details on connecting a ship's gyro to the ADCU.

Figure 3-19Internal/External Reference Menus



3.5.3 Entering Gyro Offset Values

The sensor module housing must be mounted as close to level in pitch and roll as possible, with its long axis parallel to the vessel's centerline. Sometimes allowances must be made for the particular installation where pitch, roll and azimuth references cannot be met. The offset values adjust for this. The allowable offset values for pitch and roll are $\pm 45^{\circ}$; the offset for azimuth can be up to $\pm 180^{\circ}$. Once entered, offset values will not need to be changed unless the Sensor Module is relocated.




Figure 3-20
Entering Gyro Offset Values



Pitch, roll, and yaw settings are determined by the Sensor Module's internal inclinometer, not external measurements.

To set pitch, roll, and yaw properly, initially enter zeros for all measurements. Choose the Pitch, Roll, and Yaw display from the Main Menu and record those numbers.

Reverse the value of the Pitch and Roll (positive becomes negative, negative becomes positive).

Return to the Gyro Offset menu and enter the recorded numbers.

This process should be carried out in still water or at the dock.


As noted in Section 2.2, "Mounting the Sensor Module," the sensor must be aligned to within ±5° of the vessel's fore-and-aft centerline.

Deviation beyond ±5° will degrade pitch, roll, and yaw accuracy.

3.5.4 Choosing the Default Display


This option resets the ADCU display settings to their factory defaults.

Figure 3-21
Selecting the Default Display





If the main display is set to show antenna tracking information but the antenna communications are OFF, the following display will be shown:




To correct the error, turn antenna communications ON or change the main display setting.

Figure 3-22
Selecting TracVision- or
GyroTrac-only Operations

3.5.5 Selecting TracVision or GyroTrac-only Operations


GyroTrac's factory default configuration is to operate as a standalone system (Antenna Comm is: OFF). Connecting a TracVision antenna will reconfigure GyroTrac to function as a component of a TracVision system (Antenna Comm is: ON).



3.6 Control Compass Mode

These screens are only seen if heading reference is INTERNAL.

The Compass Control function provides control over the GyroTrac sensor module, including turning autocalibration on and off, reading the calibration score, and manually clearing the compass calibration.



3.6.1 Selecting Autocompensation

These screens are only seen if heading reference is INTERNAL.

GyroTrac is fully capable of autocompensation to ensure that the navigation data is as accurate as possible.




Figure 3-24Setting Autocompensation




As noted in Section 2.6, "Calibrating the Sensor Module," a well-calibrated sensor is crucial to GyroTrac's accuracy. If you shift, remove, or add equipment near the sensor, KVH suggests turning autocompensation on so that the sensor will automatically recalibrate itself within the surrounding magnetic field.

3.6.2 Reading the Calibration Score

These screens are only seen if heading reference is INTERNAL.

The calibration score should be checked during the installation process and whenever adjustments are made to vessel equipment that can affect the compass' accuracy. A complete explanation of the compass calibration score has been provided in *Section 2.6.2*, "The Calibration Score."

Figure 3-25Reading the Calibration Score



3.6.3 Clearing Compass Calibration


These screens are only seen if heading reference is INTERNAL.

Clearing the compass calibration will reset the system to the factory defaults.


Figure 3-26Clearing Compass Calibration



After resetting this autocalibration, the following screen may appear:




This may result from a temporary lack of communication with the compass. Restart the system to restore compass data.



3.7 Antenna Status Mode

These screens are only seen if Antenna Comm is turned ON.


This sequence of steps allows a user to scan for system errors, access antenna type, version, and serial number information, check the signal and noise levels, indicate the skew angle, and display the bit error rate.



3.7.1 Antenna Status Data Screens

These screens are only seen if Antenna Comm is turned ON.

Figure 3-28 illustrates the information available through the Get Antenna Status mode. The Skew Angle and Bit Error rates are only available when the GyroTrac ADCU is connected to a TracVision G4 or TracVision G6.




3-20

3.8 Control Antenna Mode

These screens are only seen if Antenna Comm is turned ON.

This sequence of steps allows a user to adjust the antenna's azimuth and elevation manually, restart the antenna, set Sleep Mode on or off, set Instant On Mode on or off, install a new pair of active satellites, set the latitude and longitude, and select the active satellite system.



3.8.1 Manually Controlling the Antenna


These screens are only seen if Antenna Comm is turned ON.

In certain circumstances, it may be necessary to control the azimuth, elevation, and tracking of the TracVision G4 or TracVision G6 antenna manually, using the process illustrated in Figure 3-30. Use +/- to manually move the dish. Azimuth measurements are reported as relative to the bearing of the vessel's bow.

Figure 3-30
Manual Antenna
Control Procedure




If the manual adjustment of the antenna reached the maximum rotation (720°), the screen will display:



While this is displayed, the antenna will rotate 360° and return to the Manual Antenna Control screens.



YES tells the antenna to begin actively tracking the set azimuth and elevation. NO leaves the antenna halted in its current position.



3.8.2 Restarting the Antenna

These screens are only seen if Antenna Comm is turned ON.

After resetting satellite parameters, it is necessary to restart the antenna before the new settings take effect.




Figure 3-31Restart Antenna Menu


3.8.3 Turning Sleep Mode On/Off

These screens are only seen if the GyroTrac ADCU is connected to a GyroTrac-compatible TracVision system.

Only the following systems include the Sleep Mode function:

- TracVision G6
- TracVision G4 Antenna Software Version 3.02 or later
- TracVision 3 Antenna Software Version 4.20 or later

Sleep Mode turns off conical scan tracking if the antenna holds the same position for 1 minute. As soon as the vessel moves, the system will automatically begin tracking the satellite again.





To find your system's version number, use the Get Version function. Refer to Section 3.7.1, "Antenna Status Data Screens."

Figure 3-32Sleep Mode Menu



As its factory default setting, Sleep Mode is turned ON.



To find your system's version number, use the Get Version function. Refer to Section 3.7.1, "Antenna Status Data Screens."

Figure 3-33 *Instant On Mode Menu*




As its factory default setting, Instant On Mode is turned ON.

3.8.4 Turning Instant On Mode On/Off

These screens are only seen if the GyroTrac ADCU is connected to a TracVision G4 (antenna software version 3.27 or later) or a TracVision G6.

Instant On allows the antenna to immediately receive a TV signal if the vessel has not moved since the antenna was last shut off. If the vessel moves after acquiring the satellite via Instant On, the antenna will undergo its standard initialization process, resulting in a brief interruption of the TV signal.




3.8.5 Installing a New Satellite Pair

These screens are only seen if the GyroTrac ADCU is connected to a TracVision G4 or TracVision G6.

TracVision G4 and TracVision G6 permit two satellite services (Satellites A and B) installed simultaneously. There is also an option for **NONE** on satellite B, permitting single satellite operation.

Figure 3-34
Installing Satellite Pair Process



3.8.6 Setting Latitude and Longitude

These screens are only seen if the GyroTrac ADCU is connected to a TracVision G4 or TracVision G6.

When installing a satellite pair, it is also necessary to enter the vessel's latitude and longitude to ensure that the installed satellites are viewable as well as to permit the system to set several internal parameters.


Figure 3-35 Set Latitude/Longitude Procedure



If the latitude and/or longitude entered is not valid for the installed satellite pair, the following screen will appear:



Recheck and re-enter your latitude and longitude and verify your installed satellite pair to resolve this issue.




3.8.7 Selecting Active Satellite

These screens are only seen if the GyroTrac ADCU is connected to a TracVision G4 or TracVision G6.

After installing the active pair of satellites, use the Select Satellite menu to choose which of the installed satellites will be active.

Figure 3-36Select Active Satellite



54-0142 Rev. G 3-27

4 Troubleshooting

The KVH GyroTrac is designed for reliable, easy use. This section provides a brief overview of some potential operational issues that may arise.

Issue 1:

System fails startup routine and ADCU displays "Errors Detected."

Solution:

GyroTrac will not operate unless the system passes the startup self-tests. The following actions may be taken in this instance.

- Shut down the system and restore power.
- Shut down the system and verify proper wiring and dip switch settings (if your ADCU is equipped with dip switches) as detailed in Section 2.4, "Wiring the GyroTrac."
- Contact a KVH dealer or distributor for further assistance.

Issue 2:

System is installed correctly and power is available, but the system is non-functional.

Solution:


Check the 1-amp fuses within the ADCU. Remove the two screws securing the top and the base of the ADCU. Remove the top of the ADCU. The 1-amp fuses are secured in brackets on the upper and lower printed circuit boards (PCBs) within the unit. Remove the damaged fuse and replace with a new, functional 1-amp fuse.

*

TracVision-specific issues are discussed in Section 4, "Troubleshooting," of the appropriate TracVision manual.

Figure 4-1

ADCU Fuse Locations
(Top CutAway)



54-0142 Rev. G 4-1

Issue 3:

GyroTrac is connected to a GyroTrac-compatible TracVision system but there is no communication between GyroTrac and the antenna and you are unable to access antenna-specific menus on the ADCU.

Solution:

Verify that GyroTrac is configured as a TracVision component, as detailed in *Section 3.5.5*, "Selecting TracVision or GyroTrac-only Operations."

Issue 4:

There is no data output through Serial Port #3.

Solution:

Serial Port #3 provides no output when GyroTrac is configured as a component within a GyroTrac-compatible TracVision system. To make Serial Port #3 available for use with other onboard equipment, reconfigure the system as described in *Section 3.5.5*, "Selecting TracVision or GyroTrac-only Operations," to function as a standalone unit, not as a part of a TracVision system.

5 Maintenance

5.1 Warranty/Service Information

KVH Industries, Inc. warrants the GyroTrac against defects in materials and workmanship for a period of two years and labor for a period of one year from the date of original retail purchase by the original purchaser. Labor is only warrantied if the GyroTrac was installed by an authorized KVH technical dealer. It is the customer's responsibility to verify the date of purchase by returning the warranty card included with the product to KVH within 30 days of purchase, or by providing a copy of a dated sales receipt for the KVH product under warranty with the warranty claim. If this date cannot be verified, the warranty period will begin 30 days after the date of manufacture of the original product purchased.

For additional information on KVH warranty, repair, and liability policies, please refer to the complete warranty statement provided at the conclusion of this manual.

5.2 Replaceable Parts

GyroTrac has been designed with durability and low maintenance in mind. If you are experiencing an operating problem or otherwise require technical assistance, contact your local KVH dealer or distributor first. Have the GyroTrac serial number ready with a list of the trouble symptoms. If an authorized dealer or distributor is not located nearby, contact KVH directly at the telephone, facsimile, or e-mail listings inside the front cover.



The GyroTrac serial number will be required for any maintenance or troubleshooting calls. It can be found in the front of this manual, on the Sensor Module end cap, and on the back of the ADCU.

54-0142 Rev. G 5-1

Replacement parts for components that can be serviced in the field are listed in Table 5-1. These parts may be obtained from any KVH-authorized dealer/installer.


Table 5-1 Field Replaceable Units

FRU	KVH Part No.
Sensor Module	02-0991
ADCU	02-0961
Flush Mount ADCU Panel	20-0667
Horizontal Sensor Bracket	20-0658
Vertical Sensor Bracket	20-0666
Connector Wire Terminal Strip	23-0223-12
Sensor to ADCU Data Cable	32-0623-30
ADCU Fuse	16-0009-1000

Table 5-2 and Figure 5-1 provide the pin assignments for the Sensor to ADCU Data Cable (Part Number 32-0623-30).

Table 5-2Data Cable Wiring/Terminal
Assignments

Figure 5-1
Data Cable Terminal



Connector Terminal	Wire Color	Function
1	Wht/Blu Stripe	FE_TXD+
2	Blu/Wht Stripe	FE_TXD-
3	Wht/Org Stripe	FE_RXD-
4	Org/Wht Stripe	FE_RXD+
10	Wht/Grn Stripe	GND
11	Grn/Wht Stripe	+12V
Shell	Shield	

Appendix A System Specifications

The following table presents system specifications and operating parameters for the GyroTrac system.

Performance Data

Accuracy	±3.0° peak; ±1.0° typical ¹
Repeatability	±0.25°
Resolution	±0.1° (gyro ±0.01)
Tilt Angle/Pitch & Roll Range	±45°
Rate Gyro Drift	0°/minute (auto-corrected)
Maximum Angular Velocity	45°/second
Bandwidth	10 Hz
Power/Consumption	12-32VDC/330 mA (stand-alone) TracVision component: 11-16VDC 3.5 amps nominal, 4.5 amps peak
Data I/O Format	RS-422 (NMEA 0183 Version 2.2)
Zero Point Stability	±0.8°

Table A-1System Performance

Environmental Data

Operating Temperature	-25°C to +55°C (-13°F to +130°F)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Maximum Shock (Performance)	20G, 11 msec
EMI/RFI	IEC 945; FCC Part 15J, Class B

Table A-2 Environmental Specifications

54-0142 Rev. G

After calibration, free magnetic field to tilt angles of ±20°; accuracy ±5.0 RMS to ±45° tilt or roll.

Table A-3

Interface Data

Interface Assignments

NMEA 0183 ver. 2.2:			
BWC	Bearing, distance to waypoint		
GGA	GPS fix data		
GLL	GPS latitude, longitude		
HDG	Stabilized magnetic heading		
HDM	Magnetic heading		
HDT	True heading		
VTG	Course over ground, speed over ground		
XTE	Cross-track error (measured)		
Cetrek	Proprietary digital output		
Sine/Cosine			
3-wire	User-selectable reference/swing voltage		
4-wire (B&G)	set reference voltage to 3.5v		
Furuno	AD10S standard output		

Appendix B Optional KVH Displays

Three optional displays are available; each presents true or magnetic heading in a different way (see Figure B-1). The pointer analog display has a pointer rotating against a fixed 360° dial. The digital display presents heading numerically; it also displays the compass calibration score when this option is selected with the Setup Configuration function. The rotating card display has a compass card rotating under a fixed lubber line. The pointer analog and digital displays have five levels of user-selectable backlighting; the rotating card display has continuously variable red or green backlighting (the color is user-selectable).

Pointer Analog



Digital



Rotating Card



Figure B-1Display Options

B.1 Optional Display Specifications

Pointer Analog Display

Dimensions	4.3" (110 mm) x 4.3" (110 mm) x 0.8" (20 mm)	
Weight	7.5 oz (210 gm)	

Digital Display

Dimensions	6.5" (165 mm) x 4.3" (110 mm) x 0.8" (20 mm)
Weight	13.4 oz (380 gm)

Card Analog Display

Dimensions	5.6" (142 mm) x 5.6" (142 mm) x 3" (76 mm)
Weight	39 oz (1110 gm)

Table B-1Display Specifications


54-0142 Rev. G B-1

B.2 Mounting the Pointer Analog and Digital Displays

The pointer analog and digital displays both include a pigtail cable coming from inside the display housing. The following mounting instructions are applicable to both display types. Ensure the mounting surface is flat and free of excessive vibration. Do not mount the display housing on a rigid curved surface, as tightening down the nuts on the threaded studs may bend the housing and damage the unit. Refer to Figure B-2.

- 1. Using the template packed with the unit, mark the centers of the threaded studs.
- 2. Center-punch and drill 2 holes using a 3/4-inch or 20 mm bit.
- 3. Feed the pigtail cable through the right hole, then insert the threaded studs.
- 4. Attach the lockwashers and nuts provided and tighten securely.

Figure B-2Mounting the Analog/Digital
Displays



B.2.1 Mounting the Display Backlighting Control

A backlighting control button is included with the pointer analog and digital display units. Figure B-3 illustrates the mounting procedure.

- 1. Select a location convenient to the display and drill a mounting hole using a 5/8-inch (16 mm) bit. The mounting area should be no thicker than 3/8-inch (10 mm).
- 2. Insert the button and secure it from the rear with the lockwasher and nut provided.




Figure B-3
Mounting the Display Backlighting
Control Switch

B.2.2 Wiring the Pointer Analog and Digital Displays


Table B-2 details the wiring designations for the pointer analog and digital displays, including the recommended ADCU terminal strip connectors.

Wire Color	Signal Function	Recommended Terminal Connector	
White	Lighting level	Backlight Control Button	
Blue RS-422 NMEA Dat		TX1A(+) - #4	
Green	RS-422 NMEA Ref	TXB(-) - #5	
Red	12 Vdc positive	KVH Display Power – #3	
Black	12 Vdc negative	Ground – #6	
Shield/Drain	Ground	Ground – #6	
Brown	Not Used	Not Connected	

Table B-2Display Cable Connections

54-0142 Rev. G B-3

Figure B-4Wiring the Backlight
Control Switch



B.2.3 Wiring the Backlight Control Switch

- 1. Run a separate 2-conductor wire between the ADCU and the backlight control button.
- 2. Crimp terminal lugs to the two wires that will connect to the backlight control button.
- 3. Fasten the lugs to button terminals 3 and 4 (polarity does not matter) with nuts and lockwashers provided.
- 4. The other end of the 2-conductor wire will connect to the display cable and the ADCU as follows:
 - Splice one strand of the 2-conductor wire to the display cable's white wire.
 - Wire the other strand of the 2-conductor wire directly to the ADCU ground terminal.

B.3 Mounting the Rotating Card Display

The Rotating Card Display may be mounted either free standing on its bracket or flush with the panel. Templates for either method are found in Appendix E. The unit should be no closer than 36" (1 m) to any magnetic compass. Before installing, remove the display unit from its stand by removing the latch knobs on either side.

B.3.1 Bracket Mounting

- Select a site with room for the unit to rotate in its bracket. Cut out or copy Template E-1 and tape in place. Mark and drill two 1/4" (6 mm) holes as indicated. Fasten the bracket in place with the screws provided.
- 2. Reattach the display unit to the bracket temporarily until ready to make the power and data connections described in *Section B.3.3*, "Wiring the Rotating Card Display."

B.3.2 Panel Mounting

- 1. Cut out or copy Template E-2 and mark lines for the cutout area. Cut away the material inside the lines and clean up to the lines with a file. Test-fit the display unit in the cutout opening.
- 2. Remove the two 6 mm machine screws from the back of the display unit. Insert the display unit into the cutout; place the panel mounting bracket clamp in position behind the display unit. Reverse the 6 mm screws and reinsert into the case through the bracket clamp. Tighten the screws securely.

B.3.3 Wiring the Rotating Card Display

1. Refer to Figure B-5. To remove the backplate, undo 8 screws (a) and withdraw the backplate assembly. Separate the two pigtail plug connectors from the card assembly.




Figure B-5
Rotating Card Display – Removing the Backplate

2. Pass the power supply and data cables through their packing glands (b,c,d) from the outside and tighten the gland nuts before connecting wires.

54-0142 Rev. G B-5

3. Refer to Figure B-6 below; connect the power and data wires to the terminal block as listed in Table B-3.

Figure B-6Rotating Card Display – Terminal
Strip Wiring





Table B-3Rotating Card Display – Terminal
Strip Wiring Details

Term. #	Function
1	Output B (linked to term. 5)
2	Output A (linked to term. 6)
3	Shield for output cable
4	Shield for input cable
5	Input B (NMEA 0183 data)
6	Input A (NMEA 0183 data)
7	11-40 Vdc NEG (-)
8	11-40 Vdc POS (+)

4. Set the jumpers as shown in Figure B-7 to select red or green night illumination.

Figure B-7
Rotating Card Display –
PC Board Jumpers and Connectors



- 5. Check that the backplate gasket is in place; return the power and data pigtail plugs to their respective PC board connectors.
- 6. Arrange the internal wiring before replacing and tightening the backplate screws.

54-0142 Rev. G B-7

Appendix C Data Outputs

The GyroTrac transmits up to five selectable message types simultaneously to external navigation devices connected to the User Interface. One output port is dedicated to the sine/cosine signal format, one is dedicated to the Furuno AD10S signal format, and three separate serial ports allow outputs of NMEA 0183, KVH RS-422, and Cetrek proprietary signal formats. Each of these message formats is described below. Step-by-step instructions for selecting desired message outputs is given in *Section 3, "Initialization and Configuration."*

C.1 Sine/Cosine Output

GyroTrac may be configured to provide either 3-wire or 4-wire sine/cosine output, but not both. Sine / cosine output message options are magnetic or true heading and a combination of reference and swing voltages used to denote the heading value. The reference and swing voltages are set through the ADCU to suit the requirements of the device using the data. Default reference and swing voltages (as shipped) are 5.0 volts. The allowable range for reference and swing voltages is 0 to 6.5 volts in 0.01 volt increments. The sine / cosine output is commonly used in ComNav, Robertson, and other autopilots.

B&G 4-wire Sine/Cosine

The B&G 4-wire sine/cosine output (also known as "differential sine/cosine") is a substitution of the Halcyon® compass. The reference voltage should be set at 3.5V.

C.2 Serial Port Outputs

Serial ports #1, #2, and #3 may be individually programmed to output any of the message formats described below. Up to eight NMEA 0183 listening devices can be connected to each of the serial ports. Serial Port #1 also has a pass-through duplicate port. The NMEA message format conforms to NMEA 0183 version 2.20 standard for message structure. The KVH message format is an RS-422 message format giving stabilized pitch, roll and yaw data. Data output from Port 1 will be at 4800 baud while



Refer to Section 2.4.4, Wiring the GyroTrac Sine/Cosine Interface, for complete instructions on properly configuring GyroTrac and other navigational systems to use the sine/cosine output.

54-0142 Rev. G C-1

data from Ports 2 and 3 will be at 9600 baud; this message may be used in any device capable of receiving this data rate. The Cetrek proprietary message format is a stabilized heading output for use with Cetrek autopilots. Each serial port can be independently programmed to output data at a rate of 1 Hz to 20 Hz, selectable in 1 Hz increments. The default data rate is 10 Hz.

Table C-1NMEA1 Magnetic
Heading Output

NMEA1 Magnetic Heading (HDM)

•	0 ()		
Communication:	4800 baud, 1 start bit, 8 data bits, 1 stop bit, no parity		
Update rate:	Selectable at 1 to 20 Hz (10 Hz default)		
Sentence type:	\$HCHDM,XXX.X,M,* hh <cr> <lf></lf></cr>		
Sentence breakdown:	HCHDM	NMEA talker and sentence ID	
	XXX.X	Stabilized magnetic heading in degrees and tenths	
	М	Magnetic heading, ASCII hex 0x4D	
	*	ASCII hex 0x2A	
	hh	Checksum	
	CR	Carriage return, ASCII hex 0x0D	
	LF	Line feed, ASCII hex 0x0A	

Table C-2 NMEA2 Magnetic Heading Output

NMEA2 Magnetic Heading (HDG)

Communication:	4800 baud, 1 start bit, 8 data bits, 1 stop bit, no parity		
Update rate:	Selectable at 1 to 20 Hz (10 Hz default)		
Sentence type:	\$HCHDG,XXX.X, *hh <cr> <lf></lf></cr>		
Sentence breakdown:	HCHDG	NMEA talker and sentence ID	
	XXX.X	Stabilized magnetic heading in degrees and tenths	
	*	ASCII hex 0x2A	
	hh	Checksum	
	CR	Carriage return, ASCII hex 0x0D	
	LF	Line feed, ASCII hex 0x0A	

NMEA3 True Heading (HDT)

Communication:	4800 baud, 1 start bit, 8 data bits, 1 stop bit, no parity			
Update rate:	Selectable at 1 to 20 Hz (10 Hz default)			
Sentence type:	\$HCHDT,XXX.X,T *hh <cr> <lf></lf></cr>			
Sentence breakdown:	HCHDT	NMEA talker and sentence ID		
	XXX.X	Stabilized true heading in degrees and tenths		
	Т	True heading, ASCII hex 0x54		
	*	ASCII hex 0x2A		
	hh	Checksum		
	CR	Carriage return, ASCII hex 0x0D		
	LF	Line feed, ASCII hex 0x0A		

Table C-3 NMEA3 True Heading Output



True Heading is only available when GPS data input is received by the ADCU. Section 2.4.5, True North Capability, provides complete details.

KVH Format Special Output Sentence (Set at Factory Only)

Communication:	9600 baud, 1 start bit, 8 data bits, 1 stop bit, no parity			
Update rate:	Selectable at 1 to 20 Hz (10 Hz default)			
Sentence type:	%AAAA,BBBB,CCCC <cr> <lf></lf></cr>			
Sentence breakdown:	%	Sentence identifier		
·	AAAA	Stabilized pitch attitude in tenth of degrees		
	BBBB	Stabilized roll attitude in tenths of degrees		
	CCCC	Stabilized magnetic azimuth in tenths of degrees		
	CR	Carriage return, ASCII hex 0x0D		
	LF	Line feed, ASCII hex 0x0A		

Table C-4 KVH Output

54-0142 Rev. G C-3

Table C-5 Cetrek Output

Cetrek Output Sentence

Communication:	4800 baud, 1 start bit, 8 data bits, 1 stop bit, no parity			
Update rate:	Selectable at 1 to 20 Hz (10 Hz default)			
Sentence type:	\$\$MSB LSB B C Status D <cr> <lf></lf></cr>			
Sentence breakdown:	MSB LSB	Binary value 0 to 1023, equal to 0.0 to 359.6 degrees stabilized magnetic heading		
	В	ASCII hex 0x00		
	С	ASCII hex 0x00		
	Status	ASCII hex 0x43		
	D	ASCII hex 0xAA		
	CR	Carriage return, ASCII hex 0x0D		
	LF	Line feed, ASCII hex 0x0A		

C.3 Furuno Output

The Furuno output is a proprietary message format typically used with Furuno and other brands of radars and autopilots. Two user-configurable options are available: true or magnetic heading and 25 millisecond (40 Hz) or 200 millisecond (5 Hz) data rate. The default rate is 200 millisecond/5 Hz.

C.3.1 Optional Stepper Components

Stepper Interface

Figure C-1

An optional interface unit is available to generate a stepper output. The stepper interface uses an NMEA HDM or HDT serial message input to generate the stepper signal format. The stepper signal replaces traditional gyro outputs used with satellite communication systems, autopilots, and steering displays. The Stepper Interface unit is shown in Figure C-1 while the specifications are presented in Table C-6.

Please refer to the Stepper Interface User Manual for specific wiring instructions.

Stepper Interface

Dimensions	10.5" (267 mm) x 5.8" (147 mm) x 2.3" (58 mm)
Weight	13 oz (370 gm)
Input	NMEA 0183
Stepper Output	3, 6, 12, 24 steps/degree
Output Voltage	5v standard (30-70v option also available: Part Number 19-0089)

Stepper Voltage Converter


A Stepper Voltage Converter (KVH Part Number 19-0089) is needed when the receiving stepper device employs a reference voltage greater than the 5 volt maximum available from the Stepper Interface. The converter is wired directly between the Stepper Interface output and the receiving equipment to provide the necessary reference voltage. An external 6-70v DC power supply is required to provide the necessary voltage to this device. Figure C-2 on the following page shows the Stepper Voltage wiring connections and wiring diagram.

Table C-6


Stepper Interface Specifications


54-0142 Rev. G C-5

Figure C-2
Optional 6-70v Stepper Voltage
Converter Wiring Diagram




The step supply is internally fused at 1 amp. Step output lines are opto-isolated from step input lines.






Appendix E Rotating Card Display Mounting Templates

Template E-1 Rotating Card Display Bracket Mounting



54-0142 Rev. G E-1

Template E-2 Rotating Card Display Panel Mounting





54-0142 Rev. G E-3

KVH Industries Limited Warranty – GyroTrac[™]

Limited Warranty on Hardware

KVH Industries, Inc. warrants the KVH product purchased against defects in materials for a period of TWO (2) years and against labor costs for a period of ONE (1) year from the date of original retail purchase by the original purchaser. It is the customer's responsibility to verify the date of purchase by returning the warranty card included with the product to KVH within 30 days of purchase, or by providing a copy of a dated sales receipt for the KVH product under warranty with the warranty claim. If this date cannot be verified, the warranty period will begin 30 days after the date of manufacture of the original product purchased.

If you discover a defect, KVH will, at its option, repair, replace or refund the purchase price of the product at no charge to you, provided you return it during the warranty period, transportation charges prepaid, to the factory direct. Please attach your name, address, telephone number, a description of the problem and a copy of the bill of sale or sales receipt as proof of date of original retail purchase, to each product returned to warranty service. Alternatively, you may bring the product to an Authorized KVH dealer distributor for repair. If the product was installed by an Authorized KVH dealer/distributor (identified with the KVH Authorized dealer/distributor list), KVH will cover the dealer's/distributor's labor charges for warranty repairs, provided the dealer/distributor contacts KVH for pre-approval of the charges.

This Limited Warranty does not apply if the product has been damaged by accident, abuse, misuse or misapplication or has been modified without the written permission of KVH; if any KVH serial number has been removed or defaced; or if any factory-sealed part of the system has been opened without authorization.

Return Authorization

A Return Material Authorization is required prior to returning the product to KVH Industries. Please call our Technical Support Department at (401) 847-3327 or send an e-mail to techs@kvh.com to obtain the RMA number. Write the number in large, clear characters on the outside of the box. To avoid confusion and misunderstandings, shipments without an RMA number clearly visible on the outside box will be refused and returned to you at your expense. If possible, use the original box and packing material to protect the equipment from damage in shipment. KVH assumes no responsibility for warranty shipments from the customer to the factory if not shipped in the manner prescribed above.

THE EXPRESS WARRANTIES SET FORTH ABOVE ARE THE ONLY WARRANTIES GIVEN BY KVH WITH RESPECT TO ANY PRODUCT FURNISHED HEREUNDER; KVH MAKES NO OTHER WARRANTIES, EXPRESS, IMPLIED OR ARISING BY CUSTOM OR TRADE USAGE, AND SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE. SAID EXPRESS WARRANTIES SHALL NOT BE ENLARGED OR OTHERWISE AFFECTED BY TECHNICAL OR OTHER ADVICE OR SERVICE PROVIDED BY KVH IN CONNECTION WITH ANY PRODUCT.

KVH's liability in contract, tort or otherwise arising out of or in connection with any product shall not exceed the price paid for the product. IN NO EVENT SHALL KVH BE LIABLE FOR SPECIAL, PUNITIVE, INCIDENTAL, TORT OR CONSEQUENTIAL DAMAGES OR LOST PROFITS OR GOODWILL (INCLUDING ANY DAMAGES RESULTING FROM LOSS OF USE, DELAY IN DELIVERY OR OTHERWISE) ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OR USE OR POSSESSION OF ANY PRODUCT, OR ANY OTHER OBLIGATIONS RELATING TO THE PRODUCT, EVEN IF KVH HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

If any implied warranty, including implied warranties of merchantability and fitness for a particular purpose, cannot be excluded under applicable law, then such implied warranty shall be limited in duration to ONE (1) YEAR from the date of the original retail purchase of this product by the original purchaser.

Some states/countries do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state/country to state/country.

